

Updating the XpressO or XO-mini software:

- 1) Unzip the downloaded update file and copy **xpression_update** to the top level (i.e. not inside of a folder) of a USB thumb drive
- 2) Start up
- 3) Go to **[Utility]** and twice to the left to "**Software Update**"
- 4) Press **[OK]** - the XpressO will restart in update mode
- 5) When asked to, insert the drive with the "**xpression_update**" and press **[OK]** - the update will take a few minutes
- 6) When the unit has turned itself off move the power switch to "off", remove the update drive and restart.
(Sometimes the LCD backlight stays on - ignore it and turn the unit off after 10 seconds as told by the display!)

That's It!

More detailed instructions are also in the included "**XO-Update_ReadMe.pdf**"

This PDF also contains the changes of the latest updates in the "**VERSION HISTORY**" (page 3).

Don't break the USB port with a drive that is too large or by forcing it in!

If you don't have a drive that fits use a USB2 or USB3 extension or a USB-Hub!